

# CASCADE MODELS

# WOOD CHIP CAR

## No.5® COUPLER CONVERSION

1. Remove existing trucks and couplers. Discard couplers.
2. Assemble No.5® Coupler and glue lid to draft gear box by placing a tiny amount of plastic compatible cement along seams only. Cut off side mounting lugs flush with sides.
3. Drop No.5® Coupler assembly into Cascade Models coupler pocket and secure with glue or screw.
4. Check for correct coupler height, function, and clearance and make any adjustments necessary.

