

WALTHERS

BOX CAR 40' WOOD

No. 5® (#28 WITH METAL POCKET) COUPLER CONVERSION

1. Remove existing screw, lid and coupler on both ends. Save screws and lids.
2. Assemble the No. 5® (#28) Coupler with Centering Spring on top and place in coupler pocket over centerpost.
3. Place lid over coupler assembly and the cast-on coupler pocket and secure with the original screw.
4. Check for correct coupler height, function, and clearance and make any adjustments necessary.

Note: Some minor variations occur depending on type of car or production run. See individual cars listed for additional specific instructions.




Fig.1

5 (#28) Installation