

**CANADIAN RAILWAY MODEL CO.****ALL FREIGHT CARS****No.5® BODY MOUNTED COUPLER CONVERSION**

1. Assemble the No.5® Coupler per instructions and install by gluing in place or securing with a screw. Be sure the coupler is mounted exactly on centerline.
2. Check for correct coupler height, function, and clearance and make any adjustments necessary.

