



**1:29 Scale
33" Wheels**

951
1 Set




**1:32 Scale
36" Wheels**

**Uncolored Metal
Ribbed Back
Freight or Passenger Wheels**

All Metal Non-Magnetic Wheels with Free Rolling Insulated Axles
Made In the U.S.A.

©2014 Kadec® Quality Products Co.

021814



Made in the U.S.A.

#951

Uncolored Metal Ribbed Back Freight or Passenger Wheels

INSTALLATION INSTRUCTIONS

Important: Take care not to bend or damage journals during installation. Do not bend axles by forcing wheel sets. If care is not taken during installation, wheel sets will not run true.

Installation in (plastic) RIGID sideframe trucks:

Remove stock wheel sets by carefully unscrewing and removing one side frame from truck bolster. Remove old wheels. Inspect axle journals in sideframes to assure there are no burrs or rough spots. Add a puff of Kadee® #231 "Greas-em" to journals to lubricate (do not use oil). Insert one axle journal into sideframe with truck bolster still attached, then the opposite sideframe aligning axle journals and reattaching the sideframe with screw. Test wheels by spinning. If wheels do not roll freely, adjust as necessary.

Recheck coupler height with a coupler height gauge after installing wheels and make any necessary adjustments.

Made In the U.S.A.



Kadee® Quality Products Co.
673 Avenue C White City, OR 97503