


## **BACHMANN PLUS**

## No.5® COUPLER CONVERSION

- 1. Remove existing couplers and discard. Save screw.
- **2.** Modify the Draft Gear Box Lid by cutting off 1/16" from back end and cutting off the center hub flush with lid surface. See Fig. 2.
- **3.** Assemble Coupler with Centering Spring on top and coupler on bottom. Install coupler assembly over Bachmann centerpost, align modified lid and secure withscrew. See Fig.1.
- **4.** Check for correct coupler height, function, and clearance and make any adjustments necessary.

## **GE B23-7**



 $^{\text{No.5}^{\text{\tiny \$}}}$  Installation