
BROADWAY LIMITED**SY 2-8-2 MIKADO****#5 or #58 PILOT #17 NEM TENDER**

Remove the pilot coupler and retain the cover and screw.

PILOT: Carefully enlarge the width of the forward portion of the opening. File it evenly on both sides to 1/4" (.250").

If the centering spring does not fit over the post either carefully enlarge the hole in the spring or reduce the size (diameter) of the post.

Slip the spring and coupler over the post and make sure the spring fit down against the bottom of the pocket. Place the cover over the pocket and secure with the original screw. Do not over tighten the screw or the coupler will not recenter properly.

TENDER: Carefully pull out the original coupler. Compress the forks of the #17 coupler together and slip into the pocket press it in until it snaps in place. If the end of the pocket bind against the back of the coupler you may need to use the longer #18 coupler or trim the edge of the pocket until the coupler swings freely.

Check the couplers for correct height, function and clearance and make any necessary adjustments.