

# CON-COR

# GUNDERSON STACK CARS

## No.5® COUPLER CONVERSION

1. If already assembled, remove coupler pocket lid and existing couplers.
2. Assemble the No.5® Coupler with spring on top, insert into Con-Cor coupler pocket.
3. Secure coupler by placing coupler pocket lid over centerpost and glue lid in place with a small amount of plastic compatible cement placed along seams only.
4. Check for correct coupler height, function, and clearance and make any adjustments necessary.

