



E & C SHOPS

No.5® COUPLER CONVERSION

WOOD CHIP CAR

1. Remove and discard E & C Shops coupler pocket lids. Flip their coupler box over to use as cover.
2. Place Centering Spring over cast-on coupler centerpost, align and glue in place with a tiny drop of CA glue. Place the No.5® Coupler onto coupler centerpost and Centering Spring. Place E & C Shops box over centerpost and coupler assembly. Secure with furnished screw.
3. Check for correct coupler height, function, and clearance and make any adjustments necessary.

E & C Shops box. Flip box over and use as cover. Secure coupler assembly with furnished screw



No.5® Coupler

Car underframe



Centering Spring, align and CA glue in place with a tiny drop of glue

Fig.1

No.5® Installation



Car floor/body