

EASTERN CAR WORKS**ALL STREAMLINED PASSENGER CARS****#22 COUPLER CONVERSION**

1. Remove the underframe. Glue Centering Spring into box with tiny amount of glue.
2. Insert the Coupler into the mounted-on coupler box, aligning it with the Centering Spring. Glue lid on box by using small amount of plastic compatible cement along seams only.
3. Check for correct coupler height, function, and clearance and make any adjustments necessary.

Fig.1
#22 Installation