

ENGLISH MODEL TRAINS

#38 COUPLER CONVERSION

1. Remove existing couplers.
2. Assemble #38 Coupler. Glue assembly together by placing a tiny amount of plastic compatible cement sparingly along joints only.
3. Install Coupler with a 2-56 screw placed in outer hole. See Fig.1.
4. Check for correct coupler height, function, and clearance and make any adjustments necessary.

Fig.1

#38 Installation

