

IHC

***37 COUPLER CONVERSION**

- 1. Remove the existing coupler.
- **2.** Cut the 30-Series Coupler box sides down to fit between the coupler opening. (See arrow indications in Fig.1 and Introduction page 8, Fig.13).
- ${f 3.}$ File the two corners at the rear of the coupler shank round, where shown in Fig.1.
- **4.** Assemble the coupler as shown with Torsion Spring on top and Coupler on bottom. Make sure the coupler fits in coupler pocket tightly, but does not bind.
- **5.** Drill and tap existing coupler mounting hole in pilot for 2-56 threads and secure #37 Coupler assembly with 2-56 screw 1/4" long.
- **6.**Check for correct coupler height, function, and clearance and make any adjustments necessary.

GG 1 ELECTRIC

