

IHC

ALL HEAVY WEIGHT PASSENGER CARS

#505 COUPLER CONVERSION BOLSTER WITH No.5® COUPLER

6 WHEEL PASSENGER TRUCK

1. Remove trucks from car and existing coupler from truck by pulling out.
2. Install #505 Coupler Conversion Bolster Kit (includes No.5® Couplers) per instructions. See Fig.1.
3. Check for correct coupler height, function, and clearance and make any adjustments necessary.

