

IHC

# ALL STREAMLINE PASSENGER CARS 4 WHEEL PASSENGER TRUCK

## #508 COUPLER CONVERSION BOLSTER WITH No.5® COUPLER

1. Remove trucks from car and existing coupler from truck by pulling out.
2. Install #508 Coupler Conversion Bolster Kit (includes No.5® Couplers) per instructions. See Fig.1.
3. Check for correct coupler height, function, and clearance and make any adjustments necessary.

