

# INTERMOUNTAIN

# ALL ROLLING STOCK CARS

## No.5® COUPLER CONVERSION

1. If already assembled, remove existing couplers.
2. Assemble the No.5® Coupler with Centering Spring on top, insert over centerpost in box, glue on lid with a plastic compatible cement.
3. Check for correct coupler height, function, and clearance and make any adjustments necessary.

