

3-23-05 Sam

508 on forward
truck
#33 on db end.

IHC OBSERVATION
STREAM LINE PASSENGER CAR HO

Remove Roof window assembly - YMB in FLOOR.

punch out pin holding dummy coupler - the pin top is just behind the red light - it maybe hidden with scampings - cut top of pocket down to the upper surface of the inside of the pocket. Cut wide enough for the 30 series dgb. File smooth and flat.

Drill and tap the original hole for a 2-56 screw.

Assemble the #33 coupler with the spring side of the dgb on the bottom of the coupler and "without" a lid on the top.

Set coupler assembly onto platform and secure with a plastic 2-56 screw from the coupler pkg. Trim to appropriate length.

Kadee®
The Coupler People®
 HO n3 through G Scale

IHC observation
 4 wheel trucks
 streamline

