



Conversion Information

IHC (Mehano) 4-4-0 American (Steam)

Pilot: Remove crossbar that the dummy coupler clips to, from the coupler box. Carefully tap the hole for a 2-56 screw. Slip the #29 spring and coupler through the front. Cut off the "ears" and "lip" from a NO.5® box lid. Slip the long side of the modified NO.5® lid under the triangular connection of the "cow catcher" and the box. Make sure that the centerpost is through the coupler and spring and is centered on the hole on the Locomotive. Press down on the lid to make sure it is level with the top of the box. Check coupler freedom of motion. Secure with a 2-56 screw.

Tender: Use #28 and follow instructions for Talgo Truck mounting.