

# LA-BELLE

## No.5® COUPLER CONVERSION

1. Assemble the No.5® Coupler per instructions and install by securing with small wood screw on centerline and 1/4" from car end.
2. Check for correct coupler height, function, and clearance and make any adjustments necessary.

# ALL ROLLING STOCK

