


## **MANTUA**

## 0-6-0 LITTLE SIX SWITCHER

## **#37 COUPLER CONVERSION**

- **1.** Remove existing coupler pocket screws, covers and couplers. Save screws.
- **2.** Check both coupler openings with 30-Series Draft Gear Box. If not wide enough, remove material equally from both sides until opening is 5/16" wide.
- **3.** For pilot: Assemble #37 Coupler with Torsion Spring on bottom. Do not use Lid. Install coupler in pilot from below and secure with Mantua screw.
- **4.** For tender: Assemble \*37 Coupler with Torsion Spring on bottom. Install 30-Series Coupler onto tender from below and secure with Mantua screw.
- **5.** Check for correct coupler height, function, and clearance and make any adjustments necessary.



#37 Installation