

MODEL POWER TRI-ANG STREAMLINED PASSENGER CARS

#37 TRUCK MOUNTED COUPLER CONVERSION

1. Remove the truck from the underbody.
2. Remove the coupler box furnished with the car.
3. Assemble the coupler as shown in Fig. 1 and mount it on the underside of the truck.
4. Secure with flat head 2-56 screw inserted from the top and 2-56 nut on bottom of coupler. Trim screw flush with bottom of nut if necessary.
5. Check for correct coupler height, function, and clearance and make any adjustments necessary.

Fig.1

#37 Installation

