Setup

1 Install two AA Batteries in Transmitter. Display will show that the System is OFF.

2 Connect Wire Harness to Receiver. *Do not force connector.*

3 Connect Servo to Wire Harness. Match up yellow, red and black wires.

• Install four AA batteries into Receiver Battery Pack.

Note: Do not connect the Receiver Battery pack to the Wire Harness at this time.

Wake System

Press and hold the we key for at least three seconds.

Transmitter will turn on and search for receivers. Display shows that the System is Ready.

Note: *If the Display turns off, press any key to turn the display on.*

Binding Receiver to Transmitter

Press and hold the Key for one second. Display will show "SEL", then:

press and release the Key. Display will show "bnd".

Note: The next sequence must be completed within 10 seconds. *

6 Plug the Battery Pack into the Wire Harness and press the key.

Note: Write down the address shown in the Transmitter Display. This address will be needed for future communication with this Receiver.

Transmitter and Receiver are now bound & ready to use.

Press to operate the servo.

See User Guide "Getting Started" for more information on using the Kadee® Radio Control and it's features.

Note: After one hour of no activity receivers will go to sleep.

To wake Receivers: Press and hold the Key for one second. *Display will show "SEL", then:* press and release the Key.

** If the Key is not pressed within 10 seconds from applying power to the Receiver, the Binding process will fail. Remove power from the Receiver and return to **Binding Receiver to Transmitter** Step 5.

