

STEWART HOBBIES INC.

BALDWIN AS-16

#22 COUPLER CONVERSION

1. Remove the screws holding the cover to the coupler pocket, which also holds the body shell on the chassis.
2. To achieve the correct coupler height and reduce the slop in the deep box two shims will be needed. One .010" shim on top of the spring and one .015" shim under the coupler. Trim shims to fit box and enlarge center holes to fit Stewart coupler box. Assemble according to Fig.1.
3. Secure coupler assembly with screw.
4. Check for correct coupler height, function, and clearance and make any adjustments necessary.

