



Self Contained Coupler Installation self help video can be found at:
<http://www.remoteuncoupling.com/html/video.htm>

SELF CONTAINED COUPLER INSTALLATION:

1) Mount coupler on coupler platform. Be sure you use the Kadee® Coupler Height Gauge to check for the correct coupler height and trip pin clearance & coupler function.

2) Drill a hole large enough through the floor to allow the servo plug to pass through and plug into the receiver's wiring harness.

3) To complete installation, mount battery pack and receiver in desired location with double sided tape. (Clean both surfaces with alcohol wipe when using double sided tape.)

Check that the servo function indicator indicates when the coupler(s) are in their open position.

Kadee[®]

Quality Products Co.

673 Avenue C,
White City, OR 97503-1078

102312

©2012, Kadee® Quality Products Co.

