

# TYCO HONG KONG

# GG-1 ELECTRIC

## #26 COUPLER CONVERSION

1. Remove the truck assembly from the body by carefully twisting and pulling. Remove existing couplers.
2. Place #26 Couplers in truck mounted pocket following 20-Series instructions.
3. Check for correct coupler height, function, and clearance and make any adjustments necessary.

