

ULRICH

#4 COUPLER CONVERSION (METAL CARS)

No.5® COUPLER CONVERSION (WOOD CARS)

1. Remove existing trucks, coupler pocket covers and couplers. Discard couplers, save trucks and covers.
2. For metal cars: Install the #4 Coupler assembly in Ulrich coupler pocket with the #204 adaptor plate. Place lid on coupler pocket and secure assembly with Ulrich screw, see Fig.1. Either the #4 or Ulrich lid may be used.
3. For wood kits: Use a No.5® Coupler. Assemble the No.5® Coupler with Centering Spring on top and secure to car floor on car centerline and flush with car end using a small wood screw, see Fig. 2.
4. Check for correct coupler height, function, and clearance and make any adjustments necessary.

ALL ROLLING STOCK




Fig.1

METAL CARS

Fig.2

WOOD CARS

#4 or No.5® Installation