

YANKEE CLIPPER MODELS

No. 5® COUPLER CONVERSION

1. Remove existing coupler and draft gear box if already assembled.
2. Assemble the No. 5® Coupler with Centering Spring on top. Place Lid on Draft Gear Box and glue together. Use a plastic compatible cement applied sparingly along seams only.
3. Align coupler assembly on car centerline and secure to car with plastic compatible cement or an optional screw.
4. Use provided washer per instructions and Kadee® #208 and/or #209 Washers to raise coupler to correct height.
5. Check for correct coupler height, function, and clearance and make any adjustments necessary.

ALL ROLLING STOCK

Secure No. 5® Coupler assembly to car floor with glue or an optional screw. Be sure coupler is aligned and on car centerline

Use provided washer per kit instructions and Kadee® #208 and/or #209 Washers to raise coupler to correct height




Fig.1

No. 5® Installation