

## YE OLD HUFF-N-PUFF

## No.5® COUPLER CONVERSION

- 1. Remove existing coupler and draft gear box if already assembled.
- **2.** Assemble the  $^{No.}5^{\otimes}$  Coupler with Centering Spring on top. Place Lid on Draft Gear Box and glue together. Use a plastic compatible cement applied sparingly along seams only.
- **3.** Align coupler assembly on car centerline and secure to coupler mounting platform with a screw.
- **4.**Check for correct coupler height, function, and clearance and make any adjustments necessary.

## **ALL ROLLING STOCK**

