
BACHMANN**2-8-0 Consolidation**

**#916 'G' Scale for both ends
#1916 #1 scale for both ends**

Remove the truck on the tender to access the screws holding the coupler arm in place.

The pilot coupler arm is a matter of sliding the pilot wheels over to access the screws.

Once you have accessed the coupler arm, take the Bachmann coupler head off the shank (arm) our G-scale #916 or #1 scale #1916 is a direct replacement and fits just like the Bachmann coupler.

Be sure to check the coupler heights because Bachmann, as well as certain other manufacturers, are not too concerned about consistent coupler heights.